

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
* FUEL LINE					I		I		I	—	
* THROTTLE OPERATION					I		I		I	105	
AIR CLEANER		NOTE (2)					R		R	94	
SPARK PLUGS					EVERY 24,000 km (16,000 mi) I, EVERY 48,000 km (32,000 mi) R					100-104	
* VALVE CLEARANCE							I			—	
ENGINE OIL			R		R		R		R	95-99	
ENGINE OIL FILTER			R		R		R		R	97-99	
* ENGINE IDLE SPEED			I	I	I	I	I	I	I	106	
RADIATOR COOLANT		NOTE (3)			I		I		R	36-37	
* COOLING SYSTEM					I		I		I	—	
* SECONDARY AIR SUPPLY SYSTEM					I		I		I	—	