

Installation Notes:

Position the front wheel between the fork legs and insert the front axle from the left side, through the left fork leg and wheel hub.

**CAUTION:**

**\* When installing the wheel, carefully fit the left brake disc between the brake pads to avoid damaging the pads.**

Tighten the axle bolt to the specified torque.

Axle bolt torque :

59 N·m (6.0 kgf·m , 43 lbf·ft)

Fit the caliper over the disc, taking care not to damage the brake pads. Install the caliper fixing bolts and tighten to a torque of:

31 N·m (3.2 kgf·m , 23 lbf·ft)

Socket bolts (2), (3) torque:

31 N·m (3.2 kgf·m , 23 lbf·ft)