

Ref. No.	Description	Function
1	Speedometer	Shows riding speed.
2	Odometer	Shows accumulated mileage.
3	Left turn signal indicator (amber)	Flashes when the left turn signal operates.
4	Coolant temperature gauge	Shows coolant temperature (see page 15).
5	Right turn signal indicator (amber)	Flashes when the right turn signal operates.
6	Tachometer	Shows engine rpm.
7	Tachometer red zone	<p>Never allow the tachometer needle to enter the red zone, even after the engine has been broken in.</p> <p><b>CAUTION:</b></p> <p>* <i>The red zone indicates the maximum limits of engine speed and running the engine in the red zone may adversely affect its service life.</i></p>
8	Tripmeter	Shows mileage per trip.