

4. Add air to the recommended pressure.

**CAUTION:**

\* *Do not exceed 42 psi (300 kPa, 3.0 kg/cm<sup>2</sup>) or the air pressure gauge may be damaged.*

**NOTE:**

\* Do not exceed the recommended air pressure or the ride will be harsh and uncomfortable.