

INSTRUMENTS AND INDICATORS

The indicators and warning lights are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Speedometer
- (2) Odometer
- (3) Tripmeter
- (4) Coolant temperature gauge
- (5) Tachometer
- (6) Tripmeter reset knob
- (7) Oil pressure warning light
- (8) Neutral indicator
- (9) Turn signal indicator
- (10) High beam indicator

