


Front/Rear Turn Signal Bulb


1. Remove the turn signal lens (1) by removing the two screws (2).



- (1) Turn signal lens
- (2) Screws

2. Slightly press the bulb (3) and turn it counterclockwise.

3. Install a new bulb in the reverse order of removal.



- (3) Bulb