

ITEM	FREQUENCY	WHICHEVER →		ODOMETER READING							NOTE (1)
		COMES	x 1,000 km	1	6	12	18	24	30	36	REFER TO PAGE
		FIRST ↓	x 1,000 mi	0.6	4	8	12	16	20	24	
		NOTE	MONTH		6	12	18	24	30	36	
				EVERY 1,000 km (600 mi) I, L							65
	DRIVE CHAIN					I		I		I	—
	DRIVE CHAIN SLIDER					I		I		I	—
	BRAKE FLUID	(NOTE 4)			I	I	R	I	I	R	14
	BRAKE SHOE/PAD WEAR				I	I	I	I	I	I	72, 73
	BRAKE SYSTEM			I		I		I		I	14, 72, 73
*	BRAKE LIGHT SWITCH					I		I		I	81
*	HEADLIGHT AIM					I		I		I	—
	CLUTCH SYSTEM			I	I	I	I	I	I	I	18
	SIDE STAND					I		I		I	71
*	SUSPENSION					I		I		I	—
*	NUTS, BOLTS, FASTENERS			I		I		I		I	—
**	WHEELS/TYRES			I	I	I	I	I	I	I	—
**	STEERING HEAD BEARINGS			I		I		I		I	—