MAINTENANCE

nage

page		page	
62	MAINTENANCE	96	Fuse Replacement
62	The Importance of Maintenance	99	Stoplight Switch Adjustment
63	Maintenance Safety	100	Bulb Replacement
64	Safety Precautions		
65	Maintenance Schedule	105	CLEANING
68	Tool Kit		
69	Serial Numbers	108	STORAGE GUIDE
70	Colour Label	108	Storage
71	Engine Oil	110	Removal from Storage
75	Crankcase Breather		
76	Spark Plugs	111	SPECIFICATIONS
78	Final Drive Oil		
79	Throttle Operation	115	CATALYTIC CONVERTER
80	Idle Speed		
81	Coolant	116	NOISE CONTROL SYSTEM
82	Air Cleaner		(AUSTRALIA ONLY)
83	Front and Rear Suspension		
	Inspection		
84	Side Stand		
85	Wheel Removal		
91	Brake Pad Wear		
92	Brake Shoe Wear		
93	Battery		

nage