

TOOL KIT


The tool kit (1) is in the compartment box (2) behind the left side cover.

Remove the left side cover (page 48).

Open the compartment box cover (page 47).

Some roadside repairs, minor adjustments and parts replacement can be performed with the tools contained in the kit.

- 10 × 14 mm Open end wrench
- 12 × 17 mm Open end wrench
- Pliers
- 4 mm Hex wrench
- 5 mm Hex wrench
- 6 mm Hex wrench
- No. 2 phillips screwdriver
- No. 2 screwdriver
- Screwdriver handle
- Spark plug wrench
- Pin spanner
- Tool bag
- 8 mm Open end wrench



- (1) Tool kit
(2) Compartment box