

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
DRIVE CHAIN			I, L EVERY 1,000km (600mi)								73
DRIVE CHAIN SLIDER					I			I		I	—
BRAKE FLUID		NOTE (4)		I	I	R	I	I	R		16
BRAKE SHOE/PAD WEAR				I	I	I	I	I	I		85, 86
BRAKE SYSTEM			I		I		I		I		16, 85, 86
* BRAKE LIGHT SWITCH					I		I		I		92
* HEADLIGHT AIM					I		I		I		—
CLUTCH SYSTEM			I	I	I	I	I	I	I		19
SIDE STAND					I		I		I		79
* SUSPENSION					I		I		I		—
* NUTS, BOLTS, FASTENERS			I		I		I		I		—
** WHEELS/TYRES			I	I	I	I	I	I	I		—
** STEERING HEAD BEARINGS			I		I		I		I		—