

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to page	
			× 1,000 km	1	6	12	18	24	30	36		
			× 1,000 mi	0.6	4	8	12	16	20	24		
		NOTE	MONTH		6	12	18	24	30	36		
DRIVE CHAIN				I, L EVERY 1,000 km (600 mi)								94
DRIVE CHAIN SLIDER						I		I		I	100	
BRAKE FLUID		NOTE (3)			I	I	R	I	I	R	27	
BRAKE PAD WEAR					I	I	I	I	I	I	110	
BRAKE SYSTEM				I		I		I		I	27, 110	
* BRAKE LIGHT SWITCH						I		I		I	—	
* HEADLIGHT AIM						I		I		I	—	
CLUTCH SYSTEM						I		I		I	30	
CLUTCH FLUID		NOTE (3)			I	I	R	I	I	R	30	
SIDE STAND						I		I		I	102	
* SUSPENSION						I		I		I	101	
* NUTS, BOLTS, FASTENERS				I		I		I		I	—	
** WHEELS/TYRES						I		I		I	—	
** STEERING HEAD BEARINGS				I		I		I		I	—	