



## **MAINTENANCE**

page

### **85 MAINTENANCE**

85	THE IMPORTANCE OF MAINTENANCE
86	MAINTENANCE SAFETY
87	SAFETY PRECAUTIONS
88	MAINTENANCE SCHEDULE
91	TOOL KIT
92	SERIAL NUMBERS
94	COLOUR LABEL
95	AIR CLEANER
96	CRANKCASE BREATHER
97	ENGINE OIL
101	ENGINE OIL STRAINER SCREEN
103	SPARK PLUG
106	COOLANT
107	THROTTLE OPERATION
107	FRONT AND REAR SUSPENSION INSPECTION
108	SIDE STAND
109	BRAKE PAD WEAR

page

110	BRAKE SHOE WEAR
111	BATTERY
114	FUSE REPLACEMENT
116	BULB REPLACEMENT

### **124 CLEANING**

### **128 STORAGE GUIDE**

128	STORAGE
130	REMOVAL FROM STORAGE

### **131 TAKING CARE OF THE UNEXPECTED**

### **132 SPECIFICATIONS**

### **136 CATALYTIC CONVERTER**

