



| <b>(Ref.No.) Description</b>           | <b>Function</b>   |
|--|---|
| (3) Left turn signal indicator (green) | Flashes when the left turn signal operates.   |
| (4) Speedometer                        | Shows riding speed.<br>This shows your speed in kilometers per hour (km/h) and/or miles per hour (mph) depending on the type.<br>The speedometer needle will swing to the maximum scale on the dial once when the ignition switch is turned ON. |

