


Instruments

Speedometer

This is shows your speed in kilometer per hour (km/h) and/or miles per hour (mph) depend on type.



MODE button

Display Check

When the ignition switch is turned on, the speedometer needle swings to the maximum scale on the dial once, all the mode and digital segments will show. If any part of these displays does not come on when it should, have your dealer check for problems.