

Ref. No.	Description	Function
1	Speedometer	Shows riding speed.
2	Tachometer	Shows engine rpm.
3	Odometer	Shows accumulated mileage.
4	Tripmeter	Shows mileage per trip or section of route.
5	Tachometer red zone	Never allow the tachometer needle to enter the red zone, even after the engine has been broken in. <b>CAUTION:</b> * <b>The red zone indicates the maximum limits of engine speed and running the engine in the red zone may adversely affect its service life.</b>
6	Turn signal indicator (amber)	Flashes when either turn signal operates.
7	High beam indicator (blue)	Lights when the headlight is on high beam.
8	Neutral indicator (green)	Lights when the transmission is in neutral.
9	Tripmeter reset knob	To reset the tripmeter to zero (0), turn the knob in the direction shown.