

BRAKES


Front Brake

Brakes are items of personal safety and should always be maintained in proper adjustment.

The distance the brake lever moves before the brake starts to engage is called free play. Measured at the tip of the front brake lever (1), free play should be maintained at:

10–20 mm (3/8–3/4 in).

Minor adjustments can be made with the brake adjuster (4) at the lever (1).



(1) Front brake lever