

TYRES

Proper air pressure will provide maximum stability, riding comfort and tyre life.

Check tyre pressure frequently and adjust if necessary.

NOTE:

* Tyre pressure should be checked before you ride while the tyres are "cold".

On/off-road tyres are standard on this model. Select the right replacement tyres in accordance with the following specifications.

		Front	Rear
Tyre size		2.75— 21-45P	4.10— 18-59P
Cold tyre pressure kPa (kg/cm ² , psi)	Rider only	150 (1.5, 22)	150 (1.5, 22)
	Rider and one passenger	150 (1.5, 22)	175 (1.75, 25)
Tyre brand			
BRIDGESTONE		TW9	TW8
YOKOHAMA		Y962	Y962

Check the tyre for cuts, imbedded nails or other sharp objects. See your authorized Honda Dealer for replacement of damaged tyre or punctured inner tubes.