

LEFT HANDLEBAR CONTROLS

Headlight Dimmer Switch (1)

Select Hi for high beam, Lo for low beam.

Turn Signal Switch (2)

Move to L to signal a left turn, R to signal a right turn. Press to turn signal off. Move to the middle position to turn signal off (U Only).

Horn Button (3)

Press the button to sound the horn.

Headlight Switch (4)

The headlight switch has three positions, "H", "P" and "OFF" marked by a red dot to the left of "P".



H: Headlight, taillight, position light and meter lights on.

P: Position light, taillight and meter lights on.

OFF (dot): Headlight, taillight, position light and meter lights off.

(U Only)

The headlight, taillight, position light and meter lights come on when the engine is turned on.



- (1) Headlight dimmer switch
- (2) Turn signal switch
- (3) Horn button
- (4) Headlight switch