

MAINTENANCE SCHEDULE

Perform Pre-ride Inspection (Page 72). at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary.

C: Clean R: Replace A: Adjust L: Lubricate

ITEM	FREQUENCY	WHICHEVER COMES FIRST ↓	ODOMETER READING [NOTE (3)]				Refer to
			1,000 km (600 mi)	6,000 km (3,750 mi)	12,000 km (7,500 mi)	18,000 km (11,250 mi)	
		EVERY					
* FUEL LINE			I	I	I		
FUEL STRAINER		C	C	C	C		
* THROTTLE OPERATION		I	I	I	I		
* CARBURETOR-CHOKE			I	I	I		
AIR CLEANER	NOTE (1)		C	C	C		Page 118
SPARK PLUG			I	R	I		Page 110
* VALVE CLEARANCE		I	I	I	I		Page 114
ENGINE OIL	YEAR	R	REPLACE EVERY 3,000 km (1,800 mi)				Page 100
ENGINE OIL FILTER SCREEN	YEAR	C	CLEAN EVERY 3,000 km (1,800 mi)				Page 102
* ENGINE OIL FILTER ROTOR				C			Page 106
* STARTER DECOMPRESSOR		I	I	I	I		
* CAN CHAIN TENSION		A	A	A	A		
* CARBURETOR-IDLE SPEED		I	I	I	I		Page 124