


Engine Stop Switch

The three position engine stop switch (1) is next to the right handlebar grip. In “RUN”, the engine will operate. In either “OFF” position, the engine will not operate. This switch is intended primarily as a safety or emergency switch and should normally remain in “RUN”.

NOTE

* If your motorcycle is stopped with the ignition switch “ON” and the engine stop switch “OFF”, the taillight will still be on, resulting in battery discharge.



(1) Engine stop switch