

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE(1)]								REFER TO PAGE	
			x1,000km	1	6	12	18	24	30	36		
			x1,000mi	0.6	4	8	12	16	20	24		
		NOTE	MONTH		6	12	18	24	30	36		
DRIVE CHAIN		NOTE(4)		I, L, EVERY 1,000km (600mi)								63
DRIVE CHAIN SLIDER				I	I	I	I	I	I	I	—	
BRAKE FLUID		NOTE(5)		I	I	R	I	I	R		12	
BRAKE PAD WEAR				I	I	I	I	I	I		77	
BRAKE SYSTEM			I		I		I		I		12, 77	
* BRAKE LIGHT SWITCH					I		I		I		88	
* HEADLIGHT AIM					I		I		I		—	
CLUTCH SYSTEM			I	I	I	I	I	I	I		16	
SIDE STAND					I		I		I		71	
* SUSPENSION					I		I		I		70	
* NUTS, BOLTS, FASTENERS		NOTE(4)	I		I		I		I		—	
** WHEELS/TYRES		NOTE(4)	I	I	I	I	I	I	I		25	
** STEERING HEAD BEARINGS			I		I		I		I		—	