

Flooded Engine

If the engine fails to start after repeated attempts, it may be flooded with excess fuel. To clear a flooded engine, push the choke lever down to the Fully Off position (C). Open the throttle fully and pull the manual decompression lever and crank the engine several times with the kickstarter while pressing the engine stop button. Release the engine stop button and follow the "High Air Temperature" starting procedure (page 32).