

## STARTING THE ENGINE

Always follow the proper starting procedure described below.


### **▲WARNING**

- \* Never run the engine in an enclosed area. The exhaust contains poisonous carbon monoxide gas that can cause loss of consciousness and lead to death.
- \* Attempting to start the engine with the transmission in gear and the clutch engaged may result in injury or damage.

### NOTE:

- \* This motorcycle can be kickstarted with the transmission in gear by disengaging the clutch before operating the kickstarter.

### Preparation

Make sure that the transmission is in neutral. Turn the engine stop switch to  (RUN) and the fuel cock ON.


## Starting Procedure

To restart a warm engine, follow the procedure for “High Air Temperature.”

### Normal Air Temperature

$10^{\circ} - 35^{\circ}\text{C}$  ( $50^{\circ} - 95^{\circ}\text{F}$ )

1. Pull the choke lever (1) up all the way to Fully ON (A).



(1) Choke lever

(A) Fully ON

(B) Detent Position

(C) Fully OFF