

## **MAJOR COMPONENTS**

**(Information you need to operate this motorcycle)**

### **⚠ WARNING**

- \* If the Pre-ride Inspection (page 38) is not performed, severe personal injury or vehicle damage may result.**

## **SUSPENSION**

### **Front Suspension**

The front suspension system uses air assisted front forks with compression damping adjuster. The forks may be adjusted for the rider's weight and riding conditions by adjusting the air pressure, oil volume and compression damping. The standard air pressure is:  
0 kPa (0 kg/cm<sup>2</sup>, 0 psi)