

## MAINTENANCE SCHEDULE

Perform the Pre-ride Inspection (page 42 ) at each scheduled maintenance period.  
 I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY  
 C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

ITEMS	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	INITIAL MAINT.		REGULAR MAINT. INTERVAL				Refer to page
			x100km	1.5	10	20	30	40	
			x100mi	1	6	12	18	24	
			MONTH	1	6	12	18	24	
*	FUEL LINE				I		I	—	
**	FUEL STRAINER SCREEN				C		C	—	
*	THROTTLE OPERATION				I		I	70-71	
	AIR CLEANER	NOTE1		C	C	C	C	60-61	
	SPARK PLUG			I	I	I	I	67-68	
*	VALVE CLEARANCE			I	I	I	I	—	
	ENGINE OIL			R	R	R	R	62-66	
	ENGINE OIL FILTER			R	R	R	R	65-66	
*	ENGINE OIL STRAINER SCREEN IN DOWN TUBE				C		C	—	
*	DECOMPRESSOR SYSTEM			I	I	I	I	46	
**	ENGINE IDLE SPEED			I	I	I	I	69	
	DRIVE CHAIN	NOTE1		I,L	Every 500km(300mi) or every 3 month:I,L			73	
	DRIVE CHAIN SLIDER				I	I	I	74	