

Maintenance Schedule

| Items | Frequency | Whichever Comes First | | Initial Maint. | Regular Maint. Interval | | | | | Refer to page: |
|------------------------|-----------|-------------------------------|--------|----------------|-------------------------|-------|-------|-------|----|----------------|
| | | ⇒ | mi | 100 | 600 | 1,200 | 1,800 | 2,400 | | |
| | | | km | 150 | 1,000 | 2,000 | 3,000 | 4,000 | | |
| | | Note | Month | 1 | 6 | 12 | 18 | 24 | | |
| EMISSION RELATED ITEMS | * | Fuel Line | | | | I | | I | — | |
| | * | Throttle Operation | | | | I | | I | 68 | |
| | | Air Cleaner | Note 1 | | C | C | C | C | 65 | |
| | | Spark Plug | | | I | I | I | I | 77 | |
| | * | Valve Clearance | | | I | I | I | I | 73 | |
| | | Engine Oil | | | R | R | R | R | 60 | |
| | ** | Engine Oil Strainer Screen | | | | | C | | C | — |
| | ** | Engine Oil Centrifugal Filter | | | | | C | | C | — |
| | ** | Engine Idle Speed | | | I | I | I | I | I | 76 |

- * Should be serviced by your Honda dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 144).
- ** In the interest of safety, we recommend these items be serviced only by your Honda dealer.