Suspension

- 2. Check that the fasteners for the shock absorber attachment points (2) are secure.
- 3. Check for oil leaks in the shock absorber. If any rear suspension components appear worn or damaged, see your Honda dealer for further inspection.