

Maintenance Schedule

Item	Break-in Maint.	Regular Maint.	Note:	Refer to page:
Drive Chain	I, L	***	Note 1	97
Drive Chain Slider	I	I		98
Brake Shoe Wear		I		84
Brake System	I	I		81
Clutch System	I	I		68
Side Stand		I		96
* Suspension		I		78
* Spark Arrester		C		77
* Nuts, Bolts, Fasteners	I	I		—
** Wheels/Tires	I	I		87, 92
** Steering Head Bearings	I	I		—

*** every 10 operating days, about 300 miles (500 km): I, L