


- Press and hold the RESET-TRIP button for more than 1 second will restore the preset mileage.



- When the preset mileage has been exceeded, the meter will accumulate mileage with “-” in front of the digits.




Clock

The clock will show hours and minutes up to 12 : 59 without “am” and “pm”.

To reset:

1. Press the MODE-TIME button. The mode indicator will display “CLOCK”.



2. Press and hold the ADJUST button, then immediately press and hold the RESET-TIME button for more than 1 second simultaneously. “Minutes” in the display will begin to blink.

