


## HEADLIGHT AIM VERTICAL ADJUSTMENT

Vertical adjustment can be made by turning the wing nuts (1) in or out as necessary. Obey local laws and regulations.



(1) Wing nuts

(A) Up

(B) Down