

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE(1)]								REFER TO PAGE
			×1,000km	1	6	12	18	24	30	36	
			×1,000mi	0.6	4	8	12	16	20	24	
			MONTH		6	12	18	24	30	36	
	DRIVE CHAIN	NOTE(4)	I, L, EVERY 1,000km (600mi)								77
	DRIVE CHAIN SLIDER			I	I	I	I	I	I	83	
	BRAKE FLUID	NOTE(5)		I	I	R	I	I	R	14	
	BRAKE PAD WEAR			I	I	I	I	I	I	91	
	BRAKE SYSTEM		I		I		I		I	14, 91	
*	BRAKE LIGHT SWITCH				I		I		I	97	
*	HEADLIGHT AIM				I		I		I	—	
	CLUTCH SYSTEM		I	I	I	I	I	I	I	19	
	SIDE STAND				I		I		I	85	
*	SUSPENSION				I		I		I	84	
*	NUTS, BOLTS, FASTENERS	NOTE(4)	I		I		I		I	—	
**	WHEELS/TYRES	NOTE(4)	I	I	I	I	I	I	I	28	
**	STEERING HEAD BEARINGS		I		I		I		I	—	