


How to read and use the meters

Headlight selection switch

Headlight lamp selection

Select either HIGH beam or LOW beam with this switch.

HIGH beam position

LOW beam position

Select LOW beam during daylight hours.

HIGH/LOW beam selection
switch

