

Correct operation

Engine braking

Closing the throttle will start the engine braking function. If more powerful engine braking is necessary, shift down (3rd~2nd...gear) and close the throttle.

Abrupt downshifting can cause the rear tire to lock up and lose traction. Refer to the table on page 35 for instructions on downshifting.

Combine braking and the engine braking on long or steep down hill runs.