

Daily/regular inspections, and easy maintenance

Inspections must be carried out daily for safety. More thorough inspections should be carried out every 6 months, and every 12 months.

WARNING!

If regular inspections are not carried out correctly, inappropriate servicing, or neglecting to repair the motorcycle may lead to serious accidents.

- Always follow this manual or the service manual when inspecting your motorcycle.
- Repair any faults before riding.

Refer to the following pages for respective inspection / maintenance areas:

Monthly inspections.....	42
Replacement parts.....	42
Daily inspections.....	43
Maintenance parts diagram.....	44
Regular inspections.....	46
Inspections to be undertaken every	
6 months.....	47
Easy maintenance.....	48
Brake.....	49
Tires.....	54
Drive chain.....	58
Engine oil.....	60
Clutch.....	65
Battery.....	67
Fuse.....	70
Air cleaner.....	72
Cables / wires.....	75