


Only wash the motorcycle when the engine is cold.

Do not use high pressured hoses to clean the motorcycle and never aim water directly at any of the electrical areas or moving parts as this may cause damage or operating problems later.



Make sure that you do not allow water into the muffler when washing. This may create starting problems and also may lead to rusting.

