


The fuel tank cap (1) has a lever (2) with “ON” and “OFF” positions to open or close the tank vent. The fuel tank cap lever (2) should be turned to “ON” to allow fuel to flow when running the engine. Turning the lever to “OFF” will prevent fuel from flowing out of the vent hole when transporting the Mini-Trail. Always tighten fuel tank cap firmly.



La tapa del depósito de combustible (1) tiene una palanca (2) con posiciones de abierto (ON) y cerrado (OFF) para abrir y cerrar la boca de entrada del depósito. La palanca (2) de la tapa del depósito de combustible debería estar colocada en la posición de abierta (ON) para dejar que fluya combustible cuando el motor esté en marcha. Coloque la palanca en posición de cerrado (OFF) para evitar el flujo de combustible afuera de la boca de entrada cuando se transporte el Mini-Trail. Apriete siempre firmemente la tapa del depósito de combustible.