

Instruments *(Continued)*

Subtraction Trip [-TRIP]

Distance travelled is subtracted from a preset figure, since the subtraction trip was set up.

Display range: 999.0 to -1,000.0 mile or 1,607.3 to -1,609.0 km

The display locks at "-1000.0" mile ("-1609.0" km) when the read-out exceeds -1000.0 mile (-1609.0 km).

To set the subtraction trip:  P.76

Default: 000

1	2	3	4
INST. CONS.			
30.0 mpg			
AVG. CONS.			
45.0 mpg			
RANGE			
20 mile			
-TRIP			
50 mile			