

Is Your Motorcycle Ready to Ride?

- Engine Oil* Check the level and add oil if needed (page 60).
- Fuel* Check the level and add fuel (page 55) if needed. Also make sure the fuel fill cap is securely fastened.
- Drive Chain* Check the condition and slack. Adjust and lubricate if needed. Also check the chain slider, guide slider and roller for wear and replace if needed (page 98).

- Cables* Check the cable housings for wear. Check the fittings for looseness. Replace or tighten as needed.
- Nuts & Bolts* Use a wrench to make sure all accessible nuts, bolts, and fasteners are tight.
- Spark Plug & Cap* Check for looseness (page 75).