Audio System (Continued)

Using *Bluetooth®* Handsfree Calling

Bluetooth® handsfree calling allows you to make and receive phone calls using your motorcycle's audio system, without handling your mobile phone.

To use the handsfree calling, you need a *Bluetooth*® compatible mobile phone and *Bluetooth*® headsets.

- You cannot operate the handsfree calling functions by the center panel switches/Interface dial while the motorcycle is in motion.
- If Bluetooth® connection is unstable due to surrounding conditions or radio wave conditions, the handsfree calling functions may not be available.
- While talking, you may be hard to hear due to wind noise during running or external noise. In that case, try to change the position of the microphone or to adjust the windscreen height. P.136
- The audio output will switch from speaker to headset automatically when making or receiving a phone call. (Even if the headset is not connected).

Preparation

- 1 Connect with the paired mobile phone.
 - ► When the phonebook import function is enabled, the contents of the mobile phone's phonebook and call history are automatically imported to the system.

 The phonebook is updated after every connection. Call history is updated after every connection or call.

Phonebook Download: P.90

- 2 Connect the paired headsets (for rider and passenger if necessary). \$\infty\$ 88
- 3 Enter the phone screen. →P. 23

■ Making a Call

You can make calls by inputting any phone number or by using the imported phonebook, call history or speed dial entries.

To change the call mode, press ✓/→ on the 4-way key switch.

Changes the call modes as follows:

[Speed Dial] →P.105 → [Phonebook]

P.108 → [Call History] →P.108 → [Dial by Number] →P.105

To adjust the phone volume: P.71

To enable/disable a call with passenger's headset: P.90

- Certain manual functions are disabled while the motorcycle is in motion. You cannot select a grayed-out option until the motorcycle is stopped.