## To Temporarily Disengage the System

- Perform one of the following operations to disengage the system temporarily. (CRUISE SET indicator temporarily goes off but the set speed remains in memory.)
  - Apply the brake lever or pedal.
  - Rotate the throttle grip past the automatically closed position in the deceleration direction
  - GL1800/B Disengage the clutch or operate the shift lever.

- **2** To resume cruise control:
  - GL1800BD/D/DA If you are still over 20 mph (30 km/h), push and release the cruise control lever to [RES/+] side.
    GL1800/B If you are still over 30 mph (50 km/h), push and release the cruise control lever to [RES/+] side.
  - GL1800BD/D/DA If you are under 20 mph (30 km/h), use the throttle to increase road speed above 20 mph (30 km/h) and then push and release the cruise control lever to [RES/+] side.

    GL1800/B If you are under 30 mph (50 km/h), use the throttle to increase road speed above 30 mph (50 km/h) and then push and release the cruise control lever to [RES/+] side.