
To Close the Travel Trunk and Saddlebags

To close a compartment, place your hands flat on the edges of its lid and press down until it is firmly closed. Make sure the travel trunk and saddlebags "OPEN" indicator is not blinking before riding.




If the Saddlebags or Travel Trunk Won't Open (78191)

GL1800/D/DA

You can store rider and passenger helmets in the travel trunk.

Store helmets as shown in the illustration.

- Make sure the front of the helmets are facing rearward.
- Some helmets may not fit in the compartment due to their size or design.



Travel trunk

To Open the Fairing Pocket

Make sure the Honda SMART Key is activated **P**.56, and then enter the operating range with the Honda SMART Key.

Take care not to store the deactivated Honda SMART Key in the fairing pocket.

The fairing pocket is for lightweight items. Cargo in the fairing pocket should not exceed:

4.5 lb (2.0 kg)

To open the fairing pocket, press the fairing pocket opener.

Fairing pocket opener

