

I

Idling Stop Button.....	52
Idling Stop Indicator	46
Idling Stop OFF Indicator	40
Idling Stop System.....	28, 61
Ignition Cut-off System	
Banking Sensor	214
Side Stand.....	167
Ignition Switch	49, 112, 214
Indicators	44
INFO Button.....	48
Information Record.....	241
Instruments.....	22
INFO 1 display	34
INFO 2 display	39
INFO 3 display	41
Multi-information Display.....	23
Instruments, Controls, & Other Features	214
Interface Dial	48
iPhone.....	94
iPod	94

L

Labels	6
Load Limits.....	17
Loading Guidelines	17
Low Fuel Indicator.....	44
Low Oil Pressure Indicator	45, 179
Low Tire Pressure Indicator	44, 181

M

Maintenance	
Fundamentals.....	143
Importance	139
Record.....	142
Safety	139
Schedule	140
Map Color	32
Maximum Weight Limit	17
MODE Button	52
Modifications.....	17
Moving in Reverse.....	119
MT MODE.....	115
Multi-information Display	23
Basic Operations.....	24
Helpful Information.....	27
Information bar.....	25
Navigation	23
System Information.....	27
Vehicle Information	26

N

N-D Switch	52, 115
Neutral Indicator	46

O

Odometer.....	36
Oil	
Engine.....	148, 158
Final Drive.....	149, 163
Overheating	178
Owner's Manual	132, 214
Oxygenated Fuels	231

P

Parking	15
Parking Brake.....	60
Parking Brake Indicator.....	47
Parking Brake Lever.....	60
Parts Location	18
Passenger Seat Heater	
Indicator	43, 135
Passenger Seat Heater Switch.....	54, 135
PGM-FI (Programmed Fuel Injection)	
Malfunction Indicator Lamp (MIL).....	45, 179
Phone	
To End a Call.....	109
To Make a Call.....	104
To Receive a Call.....	109
Protective Apparel.....	10

Q

Quick Engine Starting	113
-----------------------------	-----