


Side Cover



The right and left side cover can be removed in the same way.

Removal

1. Open the saddlebag. ► P. 128
2. Remove the bosses.
3. Release the tab from the saddlebag cover.
4. Remove the side cover.

Installation

Install the parts in the reverse order of removal.