

Index

| | |
|-------------------------------|-----|
| sub-transmission | 142 |
| suspension, | |
| adjustment | 172 |
| damping, front | 173 |
| damping, rear | 174 |
| inspection | 175 |
| switch, | |
| AT/MT | 41 |
| drive mode select | 39 |
| headlight | 37 |
| hill start assist (HSA) | 43 |
| ignition | 36 |
| SPORT | 42 |

T

| | |
|---------------------------------|----------|
| tires, | |
| air pressure | 183 |
| flat | 223 |
| repairing | 187 |
| replacing | 188 |
| thread conditions | 185, 186 |
| tool kit | 119 |
| transporting your Honda | 206 |
| tripmeter | 27 |
| trouble, unexpected | 213 |
| troubleshooting, starting | 216 |
| turning, on level ground | 97 |

V

| | |
|--|-----|
| vehicle identification no. (VIN) | 242 |
|--|-----|