

**HANDLEBAR**

ITEM	Q'TY	DIA	TRQ	REMARKS
Handlebar pinch bolt	2	8	23	
Handlebar lever holder bolt	4	6	12	
Clutch lever pivot bolt	1	6	1.0	
Clutch lever pivot nut	1	6	5.9	
Left handlebar switch screw	2	4	1.0	
Right handlebar switch screw	2	5	2.5	

STEERING STEM

ITEM	Q'TY	DIA	TRQ	REMARKS
Steering bearing adjustment nut	1	26	–	→3-20
Steering stem nut	1	24	74	→3-20

REAR WHEEL

ITEM	Q'TY	DIA	TRQ	REMARKS
Rear axle nut	1	16	88	
Rear brake disc bolt	4	8	42	Pre-coated (ALOC) bolt, replace with a new one.
Driven sprocket nut	4	10	64	

REAR SUSPENSION

ITEM	Q'TY	DIA	TRQ	REMARKS
Shock absorber upper nut	1	10	44	
Shock absorber lower nut	1	10	44	
Swingarm pivot nut	1	14	54	Apply grease.

FRONT BRAKE

ITEM	Q'TY	DIA	TRQ	REMARKS
Brake hose oil bolt	2	10	34	
Master cylinder reservoir cap screw	2	4	1.5	
Front brakelight switch screw	1	4	1.2	
Brake lever pivot bolt	1	6	1.0	
Brake lever pivot nut	1	6	6.0	
Pad pin	2	10	18	
Pad pin plug	2	10	2.5	
Brake caliper mounting bolt	2	8	26	Pre-coated (ALOC) bolt, replace with a new one.
Caliper bleed valve	1	8	8.0	

REAR BRAKE

ITEM	Q'TY	DIA	TRQ	REMARKS
Brake hose oil bolt	2	10	34	
Master cylinder reservoir cap screw	2	4	1.5	
Master cylinder joint nut	1	8	17	
Master cylinder hose connector bolt	1	4	1.5	Apply locking agent.
Pad pin	1	10	17	
Caliper bleed valve	1	8	5.4	

PGM-FI SYSTEM

ITEM	Q'TY	DIA	TRQ	REMARKS
EOT sensor	1	10	15	Apply engine oil.
O ₂ sensor	1	12	25	
Bank angle sensor bolt	2	6	10	

IGNITION SYSTEM

ITEM	Q'TY	DIA	TRQ	REMARKS
Spark plug	1	10	16	