



- Install the two types of clutch discs to each position.

**[A] 22201-KRE-G01**

**[B] 22201-KTT-900**

- **1** Assemble clutch discs, clutch plates and pressure plate onto clutch center, while aligning "o" marks of clutch center and pressure plate.
- **2** Install the tabs of the clutch disc (outside) into the shallow slots in the clutch outer.
- Clutch inspection



Basic