


Measure the brush length.


**SERVICE LIMIT:** 6.5 mm (0.26 in)

Remove the following if necessary:

- brush holder



- nut
- washer
- insulator washers
- O-ring
- cable terminal
- insulated brush
- insulator



## ASSEMBLY

