

Reverse Riding

For reverse riding practice, make sure there are no obstacles or people in the area.

1. Make sure the transmission is in neutral and set the parking brake. Make sure the subtransmission is in H or L.
2. Start the engine.
3. Move the posi-torque speed range and reverse selector lever to the reverse position (page 13).
4. While the engine is idling, depress the gearshift pedal into reverse gear.
5. Ride the ATC cautiously in reverse by gradually opening the throttle.

NOTE:

- * The posi-torque speed range and reverse selector lever cannot be moved in the reverse position without the transmission in the neutral or 1st gear.

WARNING

- * *Close the throttle and apply both front and rear brakes carefully to stop the ATC when riding in reverse. Applying the rear brake alone may cause the front wheel to lift off the ground.*