

Quick Reference

Initial Maintenance	about 100 miles (150 km) or one month.
Regular Maintenance	about every 600 miles (1,000 km) or six months.
Pre-ride Inspection	Check the following items each time before you ride (page 27): tires, spokes & rims, leaks, engine oil, fuel, drive chain, cables, nuts & bolts, spark plug & cap, throttle, and brakes.
Fuel/Capacity	unleaded gasoline, pump octane number of 86 or higher tank: 1.45 US gal (5.5 l) reserve: 0.29 US gal (1.1 l)
Engine Oil	API Service Classification SG or higher except oils labeled as energy conserving on the circular API service label, SAE 10W-40, JASO T 903 standard MA, Pro Honda GN4 or HP4 (without molybdenum additives) 4-stroke oil or equivalent
Maximum Weight Capacity	132 lbs (60 kg) rider only (no passenger or cargo) and any accessories
Tires	Front: 2.50-14 4PR CHENG SHIN , Rear: 3.00-12 4PR CHENG SHIN Type: bias-ply, tube
Tire Pressure (cold)	Front: 15 psi (100 kPa , 1.00 kgf/cm ²) Rear: 15 psi (100 kPa , 1.00 kgf/cm ²)
Spark Plug	CR6HSA (NGK) or U20FSR-U (DENSO)