

Symptom	Cause/remedy
<p>Connected, but does not play.</p>	<p>Some <i>Bluetooth</i>® devices and applications software you use may be incompatible with the audio system and/or audio files may not be played properly. Check the recommended specifications. ➤ P. 46</p> <p>Depending on the <i>Bluetooth</i>® device and applications software you use, an audio file may not be played automatically. For playing, follow the instructions in the instruction manual of your <i>Bluetooth</i>® device.</p> <p>Depending on the <i>Bluetooth</i>® device and applications software you use, an audio file may not be played normally after receiving a telephone call, etc. Change the audio mode (➤ P. 50) or turn off the power to the audio system and then turn it on again. If it still does not play even after the aforementioned operation, check that your <i>Bluetooth</i>® device is in playable state.</p>
<p>Takes some time to start playing after turning the power on or changing the audio mode.</p>	<p>Right after the power is turned on or the audio mode is changed, the audio system may take some time to connect to an audio device and to start playing an audio file. Also, the audio system may not allow any audio control operation while preparing to play an audio file.</p>